



TECHNICAL DATA SHEET

ESFR IN-RACK SPRINKLERS

1. DESCRIPTION AND INTENDED USE

The Model EG series guard/water shields are hard-wire cages with an integrated carbon steel plate designed to surround the sprinkler and protect it from mechanical damage as well as water spray from above. The guard/water shield is intended for areas where sprinklers are installed at a low elevation and/or near a high degree of human or mechanical activity as well as where water shielding is required. The Model ES series water shields are intended for use on pendent ESFR sprinklers to protect the sprinkler's heat sensing operating element from water spray from above.

Viking Model EG-100 Sprinkler Guards/Water Shields and Model ES-75 Water Shields are intended to be used in conjunction with ESFR style sprinklers where allowed by the approvals. (Refer to the Approval Charts). The sprinkler must be used in accordance with:

1. the sprinkler's Listings, Approvals, and associated design requirements.
2. the recognized design and installations standards issued, for example NFPA, FM, EN, VdS, or LPCB.
3. the latest revisions of all applicable manufacturer's documentation.

Governmental codes, ordinances, and standards may apply and may differ from one another.

WARNING

Cancer and Reproductive Harm www.P65Warnings.ca.gov

2. LISTING AND APPROVALS

Refer to section 5 for details and requirements that must be followed.



FM Approved: Class 2091

- EG-100 Guard/Water Shield is FM Approved for use with VK506, VK510, and VK514 sprinklers.
- ES-75 Water Shield is FM Approved for use with VK500 and VK503 sprinklers.
- The Model EG Guard/Water Shield and ES Water Shield are also FM approved for intermediate-level use, such as in-rack, under conveyors, mezzanines, or other similar obstructions. Refer to the Approval Chart.





TECHNICAL DATA SHEET

ESFR IN-RACK SPRINKLERS

3. TECHNICAL SPECIFICATIONS

3.1 Materials of Construction

Parameter	Value
EG series water shield (top plate)	JIS G314 Carbon steel
EG series rivet and pins	AISI 12L14 Carbon steel
Guard (wire)	Q235 Cold drawn steel wire
Screw 6-32 x 3/8 (R.H. Phillips-slotted combination drive)	Steel with Zinc plating
ES series water shield	1075 steel per ASTM A684, 0.039" thick
In-rack ESFR sprinkler wrench	Ductile iron

3.2 Markings and Dimensions




Figure – 1: EG Series Guard/Water Shield Markings and Dimensions




Figure – 2: ES Series Water Shield Markings and Dimensions



TECHNICAL DATA SHEET

ESFR IN-RACK SPRINKLERS

4. INSTALLATION

4.1 EG-100 Guard/Shield

NOTICE


Improper installation will impeded the sprinkler operation/activation.

- Follow the procedure below to properly install the sprinkler guard/water shield.

A #2 R.H. Phillips or Flat Head screwdriver is required for installation.

1. If not already installed, install the sprinkler in the pipe fitting.
2. Loosen the screw and open the guard/water shield.
3. Place the guard/water shield around the sprinkler. Verify the sprinkler is correctly oriented inside the guard.
4. Close the guard/water shield and tighten the screw.

NOTE: Be sure the pins line up with the sprinkler frame as shown.



Improper installation will impede sprinkler operation. Ensure that the sprinkler is installed in the correct position.



Figure – 3: Installing the EG Series Guard/Water Shield



4.2 ES Series Water Shield

The concave surface of the water shield should face the sprinkler deflector as shown.

1. Install the water shield onto the sprinkler threads.
2. Rotate the water shield (or spin the sprinkler) until it is at the bottom of the threads.

NOTICE

DO NOT use the water shield to start or thread the sprinkler into the pipe fitting.

3. Install the sprinkler:
 - a. If the pipe fitting is standard, use the In-Rack ESFR sprinkler wrench. Slide the wrench sideways over the wrench boss.
 - b. If the pipe fitting is an InstaSeal fitting, do NOT use a sprinkler wrench. Refer to the IS-W2 Technical Data. For 3/4" NPT sprinklers, refer to F_021123. For 1" NPT sprinklers, refer to F_021223.
4. Tighten the sprinkler until the water shield is snug against the face of the fitting.



Figure – 4: Installing the ES Series Water Shield



TECHNICAL DATA SHEET

ESFR IN-RACK SPRINKLERS

5. LISTINGS AND APPROVALS

Sprinkler Identification Number (SIN)	Compatible Device	Thread Sizes		Nominal K-factor		FM ¹
		NPT	BSPT	U.S.	Metric	
VK500	ES-75	3/4"	20 mm	14.0	202	✓
VK503	ES-75	3/4"	20 mm	16.8	242	✓
VK506	EG-100	1"	25 mm	22.4	320	✓
VK506	EG-100	1"	25 mm	25.2	363	✓
VK514	EG-100	1"	25 mm	28.0	404	✓

1. FM approved for intermediate-level use, such as in-rack, under conveyors, mezzanines, or other similar obstructions.

6. ORDERING INFORMATION

Part Number	Descriptions	Size (NPT)	Compatible Sprinkler SINs
24988F	EG-100 ESFR Guard/Water Shield, chrome finish	1"	VK506, VK510, VK514
24988M/R	EG-100 ESFR Guard/Water Shield, painted red	1"	VK506, VK510, VK514
27489	ES-75 Water Shield, chrome finish	3/4"	VK500 and VK503
27512M/B	In-rack ESFR Sprinkler wrench, socket style, for sprinklers with ES-75 water shield (requires a 1/2" ratchet drive.	3/4"	VK500 and VK503

7. CONTACT

The sprinkler and accessories are available through Viking distributors only. Contact your local Viking sales office which can be found on our website:

Americas and Asia: www.vikinggroupinc.com/locations OR Europe, Middle East, Africa (EMEA): www.viking-emea.com/contact

Manufacturer:

The Viking Corporation
5150 Beltway SE
Caledonia, MI 49316
Tel.: (800) 968-9501
Fax: 269-818-1680
Technical Services: 1-877-384-5464
techsvcs@vikingcorp.com

Importer EU:

Viking S.A.
21, Z.I. Haneboesch
L-4562 Differdange / Niederkorn
Tel.: +352 58 37 37 – 1
Fax: +352 58 37 36
vikinglux@viking-emea.com

Asia Pacific (APAC) Main Office:

The Viking Corporation (Far East) Pte. Ltd.
69 Tuas View Square
Westlink Techpark, Singapore 637621
Tel: (+65) 6 278 4061
Fax: (+65) 6 278 4609
vikingAPAC@vikingcorp.com