

TECHNICAL DATA

MODEL EG-100 ESFR SPRINKLER GUARD

The Viking Corporation, 210 N Industrial Park Drive, Hastings MI 49058
Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com
Visit the Viking website for the latest edition of this technical data page www.vikinggroupinc.com

1. DESCRIPTION

Viking ESFR Sprinkler Guards are used in conjunction with ESFR style sprinklers where allowed by the approvals. (Refer to the Approval Charts) The guards are hardwire cages designed to surround the sprinklers and protect them from mechanical damage. They are recommended for areas where sprinklers are installed at a low elevation and/or near a high degree of human or mechanical activity.

2. LISTINGS AND APPROVALS



FM Approved: Class 2091

The Model EG-100 Sprinkler Guard is ONLY Approved for use with the following sprinklers: VK506, VK510, and VK514

Also FM approved for intermediate-level use, such as in-rack, under conveyors, mezzanines, or other similar obstructions. Refer to the Approval Chart.



3. TECHNICAL DATA

Material Standards:


Guard (flat steel): Carbon Steel Guard (wire): Cold Drawn Steel Wire

Screw: 6-32 x 3/8 (R.H. Phillips-Slotted Combination Drive): Steel

Screw Finish: Zinc Plate Rivet: Carbon Steel Pins: Carbon Steel Ordering Information:

TABLE 1: ORDERING INFORMATION AND DIMENSIONS						
Part Number	Description	Size				
	Description	NPT				
24988F	Guard, ESFR, Chrome	1"				
24988M/R	Guard, ESFR, Painted (red)	1"				







TECHNICAL DATA

MODEL EG-100 ESFR SPRINKLER GUARD

The Viking Corporation, 210 N Industrial Park Drive, Hastings MI 49058
Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com
Visit the Viking website for the latest edition of this technical data page www.vikinggroupinc.com

4. INSTALLATION

NOTICE

Improper installation can impede the sprinkler operation.

▶ Follow the procedures in this document to properly install the sprinkler guard.


Installing the ESFR Sprinkler Guard on the Sprinkler

Tool needed:

#2 R.H. Phillips or Flat Head screwdriver (not available from Viking.)

Procedure:

- 1. Loosen the screw and open the guard.
- 2. Place the guard around the sprinkler as shown. Be sure the pins line up with the sprinkler frame as shown.






TECHNICAL DATA

MODEL EG-100 ESFR SPRINKLER GUARD

The Viking Corporation, 210 N Industrial Park Drive, Hastings MI 49058
Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com
Visit the Viking website for the latest edition of this technical data page www.vikinggroupinc.com

3. Close the guard and tighten the screw.



5. OPERATION

Refer to the sprinkler technical data page for the sprinkler model used. The ESFR Sprinkler Guard is a hard-wire cage designed to surround the sprinkler and protect it from mechanical damage.

6. INSPECTIONS, TESTS, AND MAINTENANCE

Refer to NFPA 25 for Inspection, Testing and Maintenance requirements.

7. AVAILABILITY

Viking ESFR Sprinkler Guards are available through a network of domestic and international distributors. See the Viking website for the closest distributor or contact Viking.

8. GUARANTEE

For details of warranty, refer to the current list price schedule or contact us directly.

Approval Chart Model EG-100 Sprinkler Guard with VK506, VK510, and VK514								
SIN	Туре	Available Thread Sizes		Nominal K-Factor		Approvals		
		NPT	BSPT	U.S.	metric	FM ¹		
VK506	ESFR Pendent	1"	25mm	22.4	320	✓		
VK510	ESFR Pendent	1"	25mm	25.2	363	✓		
VK514	ESFR Pendent	1"	25mm	28.0	404	✓		
FM and the first model to be a second of the								

1. FM approved for intermediate-level use, such as in-rack, under conveyors, mezzanines, or other similar obstructions.